



arrow
Operator's Manual

67301403 (04/03)

HARDI® reserves the right to make changes in design,
material, or specification without notice thereof.
HARDI® and other product names are registered trademarks
of HARDI® Inc. in the U.S. and in other countries.

Index

Description.....	5	Axial blower units.....	28
Zone concept.....	5	Safety grills.....	28
Basic description of the machine.....	6	Angling of the fan blades.....	29
Frame.....	6	Air outlet width adjustment.....	31
Tank.....	6	Gearbox oil change.....	32
Pump.....	6	Air flow and power consumption charts:	
Manifold system.....	6	UNIT 30" FAN.....	33
Axial fan.....	6	Centrifugal blower units.....	34
Centrifugal fan.....	6	Introduction.....	34
Filters.....	6	Standard assemblies.....	34
Identification plate.....	7	Safety grills.....	35
Use of the sprayer.....	7	B20 booms.....	36
Recommendations.....	7	Boom folding/unfolding.....	36
Safety instructions.....	8	Elevation of the central support..	37
Operating the sprayer safely.....	8	Boom width adjustment.....	38
Handling chemical products safely.....	9	Gearbox oil change.....	39
Local poison information center.....	9	Maintenance.....	40
Mistblowing technique.....	10	Lubrication.....	40
Connecting the sprayer.....	11	P.T.O. shaft.....	40
Wheel jackstand.....	11	Diaphragm pump.....	40
Drawbars.....	12	Hyd. controlled section valves....	40
Swivel drawbar (standard).....	12	Drawbar.....	41
Turnable hitch drawbar.....	12	Axles.....	41
Adjusting the drawbar length.....	13	Filters and fittings.....	41
P.T.O. shaft.....	13	Diaphragm pumps.....	42
Installation of P.T.O. shaft.....	14	Nozzles - axial.....	42
Wheel types.....	15	Nozzles - SPV, pneumatic.....	42
Axle types.....	16	Maintenance intervals.....	44
Hydraulic system.....	17	Cleaning - Basic concepts.....	45
Setting up.....	18	Cleaning procedures.....	45
Suction filter.....	18	Cleaning the sprayer.....	46
Pressure filters.....	19	Unforeseen interruptions.....	46
Fan.....	19	Off-season storage.....	47
Main tank.....	20	Off-season storage.....	47
Clean water tank.....	21	Preparation after off-season storage..	48
Nozzles - axial.....	21	Troubleshooting.....	49
Nozzles - SPV, pneumatic.....	21	Technical data.....	52
Spout types - SPV, pneumatic.....	22	Dimensions.....	52
Agitation.....	24	Weights.....	52
Powder mixer.....	24	Wheels.....	53
Operating the sprayer.....	25	Diaphragm pumps.....	53
Plumbing diagram.....	25	General specifications.....	54
Diaphragm pumps.....	25	Warranty Policy and Conditions.....	56
Manifold Valve and Pressure Valve....	26	Notes.....	58
Pressure Manifold Valve.....	26		
Pressure Regulator Valve.....	26		
Hyd. controlled section valves.....	27		



Dear Owner,

Thank you for purchasing a HARDI® product and welcome to the ever-increasing family of HARDI® sprayer owners.

Our sprayers and accessories are rapidly becoming a familiar sight on North American farms. We believe that this results from growers becoming increasingly conscious of crop protection input costs and the vital need for cost effective spray application equipment.

Please take the time to thoroughly read the Operator's Manual before using your equipment. You will find many helpful hints as well as important safety and operation information.

Some of the features on your HARDI® ARROW sprayer were suggested by growers. There is no substitute for "on farm" experience and we invite your comments and suggestions.

Please address your correspondence to the Service Manager at one of these branches:

HARDI® MIDWEST
1500 West 76th St.
Davenport, Iowa 52806
Phone: (563) 386-1730
Fax: (563) 386-1710

HARDI® WEST COAST
5646 W. Barstow, Suite 101
Fresno, California 93722
Phone: (559) 271-3106
Fax: (559) 271-3107

HARDI® GREAT LAKES
290 Sovereign Rd.
London, Ontario N6M 1B3
Phone: (519) 659-2771
Fax: (519) 659-2821

Sincerely,

A handwritten signature in black ink, appearing to read "Tom L. Kinzenbaw".

Tom L. Kinzenbaw
President

Description




Zone Concept

The trailed HARDI® ARROW sprayers are divided into two different zones.


Working zone: with ease of use in mind; all the elements for regulating the water circuit are located at the front of the machine.

Application zone: with operator safety in mind; all the parts that come into contact with chemical products have been located at the rear of the machine.





Description



Basic description of the machine

Frame

The frame is manufactured with tensile steel channels providing great durability and resistance to vibration damage.

Tank

The tanks are made from UV resistant Polyethylene and designed with smooth, rounded contours to allow for efficient cleaning and draining. Tank capacity: 600 gallons (2300 liters).

Pump

Diaphragm pump: 363/7 HD, 540 RPM, PTO driven, 294 PSI (20 bar).

Manifold system

Total control of the water circuit is carried out by differently colored Manifold valves with pictorial symbols that simplify their use.

Axial fan

The blower is designed with thick aluminum fan blades shaped like the wings of a plane. A centrifugal clutch allows for smooth engagement and disengagement.

Volume rate: 20,600 cfm (35,000 m³/hr).

Centrifugal fan

The blower is designed with aluminum or electro-welded steel. With a robust, one-piece design, they supply air flow to different sets of spouts and air outlets.

Different volume rates: 6,500 or 10,500 cfm (11,000 or 18,000 m³/hr).

Filters

Suction filter: traps impurities present in the liquid, protecting the sprayer's components. Incorporates a 3-way valve that enables cleaning of the filter when the tank is full.




Pressure filters: permit a large volume rate and high pressure.

Description

Identification plate

The identification plate is located on the front, right-hand side of the frame, indicating the model and serial number.

The machine number is engraved on the frame, next to the identification plate.



Use of the sprayer

The HARDI® ARROW sprayer is designed for the application of chemical crop protection products and liquid fertilizers.

The equipment can only be used for this purpose. Using the sprayer for any other purpose is not permitted.

If no local law requires that the operator must be certified to use the spray equipment, it is strongly recommended to be trained in correct plant protection and in safe handling of plant protection chemicals to avoid unnecessary risk for persons and the environment when doing the spray job.



Recommendations

Although the sprayer has been applied with a strong and protective surface treatment on steel parts, bolts etc. in the factories, it is recommended to apply a film of anticorrosion oil (e.g. CASTROL RUSTILLO or SHELL ENSIS FLUID) on all metal parts in order to prevent chemicals and fertilizers discoloring the enamel. Avoid oil on rubber parts, hoses and tires.

If this is done before the sprayer is put into operation for the first time, it will always be easy to clean the sprayer and keep the enamel shiny for many years.

This treatment should be carried out every time the protective film is washed off.



Safety Instructions

SAFETY INFORMATION

WARNING



ALWAYS READ OPERATOR'S MANUAL BEFORE USING EQUIPMENT

DO NOT REMOVE ANY SAFETY DEVICES OR SHIELDS. NEVER SERVICE, CLEAN OR REPAIR A MACHINE WHILE IT IS OPERATING

WARNING



ALWAYS WATCH FOR THIS SYMBOL TO POINT OUT IMPORTANT SAFETY PRECAUTIONS

IT MEANS ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!

RECOGNIZE SAFETY INFORMATION



This is the Safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.

Follow Safety Instructions

- Carefully read all the safety messages in this manual and the safety labels fitted to the machine. Keep safety labels in good condition. Replace missing or damaged safety labels. Be sure that new equipment components include any current safety labels. Replacement safety labels are available from your authorized HARDI® dealer.
- Learn how to operate the sprayer and how to use the controls properly. Do not let anyone operate the machine without proper instructions.
- Keep your sprayer in proper working condition. Unauthorized modifications or use may impair the function and/or safety and affect the machine's life.

- If you do not understand any part of this manual and need assistance, please contact your authorized HARDI® dealer.

Operating The Sprayer Safely

1. Read the complete manual carefully and become familiar with the operation of the equipment before initial operation in each spraying season. Failure to do so may result in possible over or under application of spray solution which may drastically affect crop production and lead to personal injury.
2. Before starting the engine on the tractor unit, be sure all operating controls are in the off or neutral position, including (but not limited to) the P.T.O. shaft and/or spray controls. Be sure the tractor power train is disengaged.
3. Operate spray and boom functions only when seated in the operator's seat.
4. One of the most frequent causes of personal injury or death results from persons falling off or being run over. Do not permit others to ride on or in. Only one person should be working the machine when in operation.
5. Before leaving the tractor seat, stop the engine, put all controls in neutral, and put the transmission control lever in the park position or neutral with the brakes locked. Read the tractor operation manual for added safety precautions.
6. P.T.O. driven equipment can cause serious injury. Before working on or near the P.T.O. shaft, servicing or cleaning the equipment, put P.T.O. lever in the DISENGAGE position and stop the engine.
7. Keep hands, feet & clothing away from moving parts.
8. Wear relatively tight and belted clothing to prevent from being caught on some part of the machine.
9. Stay clear of the air inlet and outlet while the fan is in use. Some objects (small stones, etc.) can be expelled from the outlet or clothing can be sucked into the inlet.
10. Always keep children away from your sprayer and/or tractor unit.
11. Slow moving tractors and spray equipment can create a hazard when on public roads. Avoid personal injury or death resulting from any accidents by using flashing lights. Local regulations may require installation of flashing warning lights.

Safety Instructions

12. Avoid injuries from high pressure fluids penetrating the skin by relieving system pressure before disconnecting hydraulics or other lines. Ensure all fittings are tight before applying pressure to the system.
13. Understand service procedures before undertaking any maintenance. Never lubricate, service, or adjust the machine while it's moving. Securely support any components before working on them.
14. Keep all parts in good condition and properly installed. Fix damaged parts immediately. Replace worn or broken parts. Remove excessive buildup of grease, oil or debris.
6. Extreme care should be taken in measuring spray products. Powders should be used in suitable sized packages or weighed accurately. Liquids should be poured into a suitable graduated container. Keep chemical containers low when pouring. Wear a filtered respirator and let the wind blow away from you to avoid dust and/or splashes contacting the skin or hair.
7. Store chemicals in a separate, plainly marked locked building. Keep the chemical in its original container with the label intact.
8. Dispose all empty containers after rinsing in accordance with local regulations & by-laws. Dispose of all unused chemicals and left over fertilizer in an approved manner.

Handling Chemical Products Safely

1. Direct exposure to hazardous chemicals can cause serious injury. These chemicals can include lubricants, coolants, paints, adhesives and agricultural chemicals. Material Safety Data Sheets (M.S.D.S.) are available for all hazardous chemicals which inform the user of specific details including: physical and health hazards, safety procedures, and emergency response techniques.
2. Protective clothing such as rubber gloves, goggles, coveralls and respirator must be worn while handling chemicals. All protective clothing should be kept in excellent condition and cleaned regularly or discarded.
3. If chemicals come in contact with any exposed skin areas, wash immediately with clean water and detergent. Never place nozzle tips or any other components that have been exposed to chemicals to lips to blow out obstructions. Use a soft brush to clean spray nozzles.
4. Dedicate an area to fill, flush, calibrate and decontaminate sprayer where chemicals will not drift or run off to contaminate people, animals, vegetation, water supply, etc. Locate this area where there is no chance of children coming in contact with this residue.
5. Decontaminate equipment used in mixing, transferring and applying chemicals after use. Follow the instructions on the chemical label for the correct procedure required. Wash spray residue from outside of the sprayer to prevent corrosion.

9. Keep a first aid kit and fire extinguisher available at all times when handling chemicals.

Local Poison Information Center

If you live anywhere in the United States, the following toll free number will connect you to your Local Poison Information Center.

PHONE NO. 1 - 8 0 0 - 2 2 2 - 1 2 2 2

If you live outside the United States, find the number for the poison control center in your phone book and write it in the space below:

PHONE NO. _____ - _____ - _____

Keep a list, in the space provided below, of all the chemicals that you have in use.


1. _____
2. _____
3. _____
4. _____
5. _____
6. _____
7. _____
8. _____
9. _____
10. _____



Safety Instructions

The safety and efficiency of this machine depend entirely on the care it receives. The first important step is to **read carefully and pay attention** to this instruction book which contains essential information on the efficient use and servicing of this high-quality product.

As this instruction book includes all the HARDI® ARROW models, please pay particular attention to those paragraphs that deal with the model that interests you.




This book should be read in conjunction with the “Mistblowing Technique” manual (#673706, supplied with the equipment), to help you to achieve the best results.



CAUTION. This product line is very versatile due to the large range of optional extras available and their possible combinations. The most commonly used technical data for air flow, power consumption and dimensions, is included in this book. Please contact your nearest dealer if you need additional information.

Connecting the sprayer




Wheel jackstand

The HARDI® ARROW sprayer is equipped with a wheel jackstand. When the sprayer is not attached to the tractor, the wheel jackstand should be locked into Position 1 with the two pins (see photo). The height of the machine can be adjusted by turning handle **A**.

When the sprayer is attached to the tractor, the wheel jackstand should be locked into Position 2 with two pins. This position is designed to fit snugly to the frame and avoid vibrating noises produced by the wheel.

Position 1



Sprayer unattached

Position 2




Holding posn.

Sprayer attached



Connecting the sprayer




Drawbars

There are two types of drawbars available for the HARDI® ARROW sprayer: the swivel drawbar, and the turnable hitch drawbar.

Swivel drawbar (standard)


The swivel drawbar is attached close to the body of the tractor. Before connecting the P.T.O. shaft, make sure that the drawbar is firmly attached and that the tractor's wheels do not touch the sprayer when turning.

A P.T.O. shaft with CV (Constant Velocity) joint is needed on the tractor's side. It is possible to adjust the length of the drawbar if necessary (see "Adjusting the drawbar length", page 13).



Turnable hitch drawbar

The turnable hitch drawbar is connected to the tractor's lower link arms. Before connecting the P.T.O. shaft, make sure that the diameter of the connecting pins is the same diameter as the holes on the tractor's lower link arms. Also make sure that the snap locks are in place and that the tractor's wheels do not touch the sprayer when turning. This hitch type permits the greatest turning angles and requires a P.T.O. shaft with CV joint on the sprayer side. The length of the drawbar is adjustable (see "Adjusting the drawbar length", page 13).




Connecting the sprayer



Adjusting the drawbar length

Steps to follow:

1. Place the wheel jackstand in the position indicated in the photo.
2. Loosen the two bolts **A**, located where the drawbar is attached to the frame.
3. Remove bolt **B**.
4. Place the drawbar in the desired position.
5. Replace bolt **B**, making sure that it passes through the holes in the frame and the drawbar.
6. Tighten the two bolts **A**.



P.T.O. shaft

Operator safety



WARNING: ALWAYS STOP ENGINE BEFORE ATTACHING THE TRANSMISSION SHAFT TO TRACTOR P.T.O. MOST TRACTOR P.T.O. SHAFTS CAN BE ROTATED BY HAND TO FACILITATE SPLINE ALIGNMENT WHEN ENGINE IS STOPPED.

When attaching the shaft, make sure that the snap lock is FULLY ENGAGED - push and pull shaft until it locks.



WARNING: ROTATING TRANSMISSION SHAFTS WITHOUT PROTECTION GUARDS ARE FATAL.

Always keep protection guards and chains intact and make sure that the guards cover all rotating parts, including CV-joints at each end of the shaft.

Do not use without protection guard.

Do not touch or stand on the transmission shaft when it is rotating - safety distance: min 5' (1.5 meters).

Prevent protection guards from rotating by attaching the chains, allowing sufficient slack for turns.

Make sure that protection guards around the tractor P.T.O. and implement shaft are intact. Always STOP ENGINE and remove the ignition key before carrying out maintenance or repairs to the transmission shaft or implement.

Connecting the sprayer


Installation of P.T.O. shaft




WARNING: THE P.T.O. SHAFT ANGLE WILL CHANGE WHEN RAISING AND LOWERING THE CLEVIS. TO PREVENT EXCESSIVE LOADING AND BINDING ON THE P.T.O. SHAFT, IT MAY BE ADVISABLE TO LEAVE THE P.T.O. SHAFT DISCONNECTED UNTIL THE CLEVIS ADJUSTMENT IS COMPLETED. THEN THE P.T.O. SHAFT ADJUSTMENTS CAN BE MADE.

Initial installation of the shaft is done as follows:


1. Attach sprayer to tractor and set sprayer in the position with shortest distance between the tractor and sprayer pump P.T.O. shafts.
2. Stop the engine and remove ignition key.
3. If P.T.O. shaft must be shortened, the shaft is pulled apart. Fit the two shaft parts at tractor and sprayer pump and measure how much it is necessary to shorten the shaft. Mark the protection guards.



Note: The shaft must always have a minimum overlap of 1/3 the length.




4. The two parts are shortened equally. Use a saw, and file the profiles afterwards to remove burrs.




5. Grease the profiles, and assemble male and female parts again.
6. Fit the shaft to tractor and sprayer pump.

Note: Female part towards tractor. Fit chains to prevent the protection guards from rotating with the shaft.

7. To ensure long life of the P.T.O. shaft, try to avoid working angles greater than 15°.



Connecting the sprayer



Wheel types

HARDI® ARROW sprayers are standard equipped with 10.0/80 12" rims and tires.

WHEELS (Tires & Rims)		
Model	Standard	Optional
Arrow 270	10.0/80 12" (8 ply)	275/50 R15"

Working pressure: 45 psi (3.1 bar) for standard 10.0/80 12" tires
 51 psi (3.5 bar) for optional 275/50 R15" tires

The sprayer's tires should always be at the correct pressure as they act as a suspension system when the tank is full, making the whole assembly less rigid.

Inflation and checking of the tire must always be done when the tire is cold. The sprayer's wheels are IMPLEMENT type and cannot exceed 25 mph (40 km/h) when fully loaded.







Connecting the sprayer



WARNING. The tires for ARROW sprayers MUST NOT BE LIQUID-FILLED.
 HARDI® will not be held responsible for the consequences or damage that this practice may have on its sprayers.
 Always maintain the recommended pressure to get normal wear and life from the sprayer's wheels, and to avoid punctures and unnecessary strain.




LIQUID FILLING NOT POSSIBLE
 with IMPLEMENT wheels provided



Axle types

HARDI® ARROW sprayers are equipped with a fixed axle with a tread width of 39" between tire centers.

FIXED AXLE



Connecting the sprayer



Hydraulic system

Connection requirements for HARDI® ARROW sprayers are:

- Two single acting outlets (one for each hydraulically controlled section valve).
- The 2-row Grape Boom can be equipped with an optional 3-cylinder hydraulic kit which requires 3 double acting hydraulic tractor outlets.



BE SURE TO HOOK UP HYDRAULIC LINES PROPERLY!

ENSURE HYDRAULIC LINES HAVE NOT BEEN DAMAGED DURING SHIPPING.

ESCAPING HYDRAULIC FLUID UNDER PRESSURE CAN PENETRATE THE SKIN CAUSING SERIOUS INJURY. AVOID THIS HAZARD BY RELIEVING PRESSURE BEFORE DISCONNECTING HYDRAULIC LINES.

ENSURE ALL CONNECTIONS ARE TIGHT BEFORE APPLYING PRESSURE, SEARCH FOR LEAKS WITH A PIECE OF CARDBOARD, NOT YOUR HANDS!

IMPROPER HOOK-UP CAN CAUSE DANGEROUS BOOM MOVEMENTS AND/OR DAMAGE TO THE SPRAYER HYDRAULICS.

DO NOT ALLOW ANYONE NEAR A HYDRAULIC BOOM IN OPERATION.

ALWAYS SHUT TRACTOR OFF WHEN CONNECTING, SERVICING OR ADJUSTING ANY HYDRAULIC COMPONENTS.

Make sure that the hydraulic couplers are clean before connecting to the tractor's remote outlets.



IMPORTANT! Due to the variation in tractor hydraulic systems and capacities, care should be exercised when initially operating the sprayer hydraulic section valves. It is advisable to adjust the hydraulic flow down to the minimum rate before operating the system. Adjust/increase the flow control after the system is bled of any air, if necessary.

Setting up



Suction filter

The suction filter is located at the front of the sprayer near the pump. Its primary purpose is to protect the pump from damage. It contains an automatic shut off valve to allow the operator to clean and service the filter with a full tank.

Cleaning the Suction Filter

Turn the yellow handle counter-clockwise until it “pops out”. This closes an internal valve to prevent the main tank from draining when cleaning the filter. Unscrew the large plastic nut and remove the lid. Remove the filter for cleaning, being very careful not to damage the O-ring of the filter lid. This would allow air to enter during suction and cause rattling of hoses and continual pressure variations. To help prevent this, it is advisable to lubricate the o-ring with vegetable oil before closing the lid. Finally, replace the yellow valve handle and lock into position to allow flow through the filter.



Warning. The suction filter is one of the most important elements of the fluid circuit. The ability of the pump to take in air correctly largely depends on how well the filter has been cleaned and maintained. It is necessary to clean the filter after every working day in order to keep the filter free of blockage.





Setting up



Pressure filters

The Arrow sprayers are equipped with in-line pressure filters to provide a clean flow of liquid to the nozzles. This is the last filter before the nozzles, and will prevent the nozzles from becoming clogged with leftover product residue solidifying in the hoses.

The in-line filters should be cleaned daily. Unscrew the filter bowl to inspect and clean the filter. Lubricate the O-ring with vegetable oil.



Fan



When working with spray guns or just liquid agitation, use of the fan is not required and it is recommended to disconnect it.



WARNING. Both the pump and the fan must be completely at rest when the position (speed) of the fan gear box is changed.

The gearbox is located behind the tank. Place the handle in the neutral position  to prevent the fan from turning with the functioning PTO, in the position  to work with a slow air speed, or in the position  for a fast air speed.

If the sprayer is equipped with a single-speed gearbox, it will only be possible to choose between neutral  and the fast speed .



NOTE.

If you encounter any difficulty when changing the gear on the fan, it is because the gear teeth are touching those on the large tooth-wheel and preventing them from falling into place. In this case the fan should be made to rotate again, then stopped, and a new attempt made.

Setting up




Main tank

To fill the tank with water, remove the lid found on top of the tank. Always use water as clean as possible. Always fill the tank with the filter basket correctly in place to prevent impurities from entering the tank.

Main tank lid Clean water tank lid



WARNING. Do not place the filling hose inside the tank. Keep it out of the tank at all times and only point it towards the inside. If the hose were inside the tank and the pressure from the water supply point dropped, the chemical products could be siphoned from the tank to the water supply, contaminating the water therein (A).





To empty the tank with the drain valve, pull the red handle located on the upper right-hand side. The valve is spring-loaded to return it to the closed position, but can be kept open by pulling the string out and upwards into the V-shaped slot (1). To close the drain valve again, pull the red handle down and release (2). The valve will close automatically (B).

Setting up



Clean water tank

The clean water tank has a capacity of 4 gallons (15 liters) and is situated at the top of the main tank. It is used for washing gloves or hands that have been in contact with the chemical product. The valve **A** for releasing the water is attached by a bracket to the front left-hand side.





WARNING. The water in this tank is not for drinking.



Nozzles - axial

The nozzles can be shut off individually by turning them 90°. When open, the nozzle has 3 different positions, all of which are readily interchangeable. Turning them slightly in either direction will produce a noticeable click.

The nozzle holders are fitted with a non-drip valve **1** which prevents loss of remaining product in the tubes after the sections have been closed.



Nozzles - SPV, pneumatic

Pneumatic machines use calibrated ceramic nozzles while SPV models or high pressure pneumatic machines use low volume nozzles.

The ceramic nozzle has two positions, the face with the conical hole provides a greater volume rate than that with the flat hole.



The ranges of volume rates vary according to the color of the nozzle.

To find out the different volume rates, you can consult the "Mistblowing Techniques" book.


Setting up

Spout types - SPV, pneumatic

There are two different types of spouts or outlets for the SPV and pneumatic machines. For pneumatic spraying there are various combinations available to suit your requirements.



These spouts can be adapted manually to suit the crop, no spanner is needed.




The pneumatic paraflow model's spouts can also be individually adjusted to point towards the areas that you wish to spray.

P
A
R
A
L
L
E
L
F
L
O
W




The height of the spout assembly can also be adjusted, and the width adapted to suit the row spacing. Loosen the nut (S) and move the bracket up or down. In order to alter the width, loosen the two r (T).



Setting up

Spout types - SPV, pneumatic


The paraflow spouts are connected in pairs, and these can be closed together (A), or individually (B) with the valves incorporated for this purpose.




The SPV model's spouts (T) are wider than most others because they need a greater air flow to properly produce the turbulence needed from the high pressure nozzles.

This type of spout can be height-adjusted and tilted upwards or downwards. These adjustments are carried out by loosening the nut (R).


It can also be directed forwards or backwards by using the handle (S).



The white spouts (M) with high pressure nozzles can be moved in the same way as the 2, 3 or 4-way spouts; height adjustment (N), or tilting upwards or downwards (O).




Setting up



Agitation

The agitation system is the "venturi" type, which pressure injects the product from the pump together with the return chamber flow.

The agitator is standard fitted with a 5 mm restrictor (A). This restrictor creates a high pressure flow which enters the main tank, provoking turbulence and ensuring a perfect mix of product and water.



The restrictor should be replaced in the following way:

- 1 With the help of a spanner, undo the nut on the inside of the agitator.
- 2 Undo the restrictor screwed into the stainless steel tube.
- 3 Put teflon on the new restrictor and screw it in.
- 4 Replace this assembly in the agitator.



Powder mixer

The sole function of the Powder mixer is to rinse the filter basket on the main tank's filling device when adding powdered products that do not dissolve properly and would otherwise form lumps on contact with the water in the tank.

After using the powder mixer it must be **turned off**, as it uses a large amount of the available flow.




Operating the sprayer




Plumbing diagram

The HARDI® ARROW sprayers use manually controlled operating units with hydraulically controlled section valves.

arrow 270 - HC/2




- | | |
|---------------------------------|-------------------------------------|
| 1. Main tank | 7. Safety valve |
| 2. Suction filter | 8. Agitation |
| 3. Pump | 9. Powder mixer |
| 4. Agitation/Powder mixer valve | 10. Hydraulic remote section valves |
| 5. Pressure regulator | 11. Pressure filters |
| 6. Manifold pressure gauge | 12. Blower nozzles |



Diaphragm pumps

The HARDI® diaphragm pumps are low pressure pumps of rugged construction. They are lubricated with grease through the grease nipples that are located on the crankshaft.

The 363/7 HD diaphragm pump has six diaphragms and a flow rate up to 37.0 gpm (140 l/min) at 540 rpm.



363



Operating the sprayer




Manifold Valve and Pressure Valve


The sprayer controls are located at the front of the sprayer. They consist of one manual pressure manifold valve and one pressure regulator valve.

Pressure Manifold Valve


The pressure manifold valve has three positions:



Pressure agitation



Off




Powder mixer


Turn the valve to the left to send pressure to the agitator (fast agitation). Turn the valve to the right to operate the powder mixer, which will clean any product residues from the filter basket. Turn the valve straight up or down to turn both features off.

Note: When pressure agitation is not selected, there is still return (slow agitation) to the tank.

Graphic symbol descriptions




Pressure agitation



Powder mixer

Pressure Regulator Valve

The pressure regulator valve is centrally located for easy calibration and allows for simple change of application rates. The 4" pressure gauge located nearby is easy to read from the ground or tractor.



Pressure regulator valve


Operating the sprayer



Hydraulically controlled section valves

The left and right blower nozzles are turned on and off by the left and right hydraulic section valves.

Make sure each hydraulic hose is connected to a separate single-acting hydraulic outlet on the tractor. The nozzles for each section are turned "On" by pushing the hydraulic lever for that section in one direction, and turned "Off" by pushing the hydraulic lever for that section in the opposite direction. The hydraulic lever can be returned to the neutral position after switching a section "On" or "Off".



If you do not like the direction required to activate a nozzle section, switch positions of the hose in the single-acting outlet for that section.

Axial blower units



Safety grills

All models of axial blower units are equipped with safety grills. These are essential for preventing accidents and the entrance of foreign objects into the blower.



WARNING.

The use of the blower unit without safety grills is absolutely **FORBIDDEN**.


Do not remove the safety grills while the machine is in use.

Do not approach a blower in use wearing light or loose clothing.


Do not introduce foreign objects into the safety grills whether the blower is in use or not.

During the working day, wear proper hearing protection to protect your hearing from the noise produced by the blower.

In the case of vibrations or knocking, stop the blower immediately.



Axial blower units




Angling of the fan blades

The angle of the fan blades can be adjusted through three positions. The standard factory setting is the second, or middle, position.


To change the angle of the fan blades, take the following steps:

A. Remove the grill (1) and the fan housing (2).

B. Remove the fan hub and clutch (3) to enable removal of the propeller from the gearbox's axle. We recommend that you place the propeller on a table top to work comfortably.



C. Unscrew the two screws that join the two support rims located between the blades (4). Remove the outer support rim and leave the inner one fixed to the hub casing (5), which is held in place by various roll pins (6) located at its rear.




Axial blower units

D. The inner part of the support rims and the fan blade neck have three grooves (8) with which the angle of the blades is adjusted.

The grooves on the fan blade are designated P1, P2 & P3,
The grooves on the support rims are designated C1, C2 & C3.


For the correct alignment of the fan blade angles in the support rims of the fan, there is one round key that fits into the grooves.



E. For the first position (35°) P1 must align with C1, in other words the first groove on the fan blade with the first groove on the support rim (9).

For the second position (40°, standard factory setting) P2 must align with C2, in other words the middle groove on the fan blade and the support rim (10).


For the third position (45°) P3 must align with C3, in other words the third groove on the fan blade and the support rim (11).




**Always align the grooves
P1-C1, P2-C2, P3-C3**

IF P3-C2 or P2-C1 ARE ALIGNED BY MISTAKE
THE FAN BLADE WILL HAVE TOO GREAT AN
ANGLE WITH THE CONSEQUENT RISK OF
BURNING THE FAN CLUTCH.

Consult your nearest dealer about modifications
to the fan blade angles.



Axial blower units



Air outlet width adjustment

Depending on the wind conditions, crop growth stage, leaf size, forward speed of the tractor and the row spacing, it may be necessary to alter the width of the air spout. The width of the fan housing of every fan that leaves the factory is set in the middle position.

Field trials have shown that the best penetration and treatment efficiency is achieved when the droplets reach the outer leaves of the tree at a speed of between 18 and 27 mph (8 and 12 m/s).

As a guide, here are three different cases :

Minimum separation

- Windy conditions.
- Small trees.
- Low leaf density.
- Row spacing greater than 20 ft. (6 meters.)

Medium separation

- Calm or gentle breeze.
- Medium-sized trees.
- High leaf density.
- Row spacing equal to or less than 20 ft. (6 meters.)


Maximum separation

- Calm conditions.
- Large trees.
- Very high leaf density.
- Row spacing less than 20 ft. (6 meters.)


To alter the width of the fan housing carry out the following steps:

A. Undo the eight nuts (1) that fix the fan housing (2), remove the fan housing and the safety grill (3).

B. Place the 15 mm spacers on the inner or outer part of the fan housing. In the case of there being two spacers together, they should be placed on the side of the cone (4).



30" FAN	A (mm)
Minimum	135
Middle STANDARD	150
Maximum	165



Axial blower units



Gearbox oil change




Please respect the environment.
RECYCLE THE OIL

The blower unit's gearbox is one of the mechanical elements that is put under the greatest strain.

During the spraying season, the gearbox oil level should be checked regularly and changed at the recommended intervals (see maintenance section).


1. Level indicator
2. Oil fill
3. Oil drain

Unit: 30" FAN




The oil fill is at the top of the mechanism, behind the tank.

SAE-20/50 MULTIGRADE or **SAE-90** oil should be used in areas with high temperatures.




Axial blower units




UNIT 30" FAN : Air flow and power consumption




40° (position 2) For tractors of more than 40 hp (35kW).
Standard factory assembly. This position gives the most efficient relationship between fuel consumption and air volume rate.




• There is no low gear.




• There is no low gear.



45° (position 3) For tractors of more than 55 hp (40 kW).
Recommended for medium-sized trees, or for working speeds of more than 2.5 mph (4 km/h) on small trees or two-sided treatment of vineyards.



• There is no low gear.



• There is no low gear.

Centrifugal blower units



Introduction

HARDI® ARROW sprayers possess a full range of spv and pneumatic blower wheels, made of steel and aluminum. Aerodynamic research of the blowers have resulted in improved air distribution, less noise and lower power consumption. A range of between 6500 and 10,500 cfm (11,000 and 18,000 m³/h) of air is obtained, depending on the model and the type of blower wheel chosen.

BLOWER WHEELS			
Sprayers			
Type	Equipment	Assemblies	Flow cfm (m ³ /h)
SPV	F400	10 spouts - maxi	10,500 (18,000)
PNEUMATIC	P540	B 20 M/H - B, C	6500 (11,000)

SPV: Blower unit with tubular steel centrifugal blower wheel.

Pneumatic: Blower unit with radial aluminum blower wheel.

B20 M/H: Blower unit with B20 manual or hydraulic boom.



WARNING. With your safety in mind: the blower unit is potentially the most dangerous part of the machine. Do not attempt to alter any part of it without consulting your nearest dealer. The manipulation of blower units to alter their characteristics should only be carried out by qualified personnel.


The technology developed on these blower units enables them to be fitted with a wide range of optional equipment that personalizes the machine to suit different areas, customers, crops or countries. Among the optional equipment available, there are: Hydraulic or suspension-loaded booms, hydraulically-lifted central support, paraflows, pneumatic or white spouts, leaf guard, mobile vertical extensions, etc...





Standard assemblies

The assemblies: B has six outlets and white spouts with four ceramic nozzles, C has eight outlets and white spouts with three ceramic nozzles.


B20 M



B20 H



B



C

Centrifugal blower units



Safety grills

All models of spv and pneumatic blower units are fitted with safety grills. These are essential to avoid accidents and the entrance of foreign objects into the blower.



WARNING.

The use of the blower unit without safety grills is absolutely **FORBIDDEN**.

Do not remove the safety grills while the machine is in use.




Do not approach a blower in use wearing light or loose clothing.

Do not introduce foreign objects into the safety grills whether the blower is in use or not.

During the working day, wear proper hearing protection to protect your hearing from the noise produced by the blower.

Prevent the booms from making contact with electric cables.

In the case of vibrations or knocking, stop the blower immediately.




Centrifugal blower units




B20 booms

The B20 boom assemblies enable HARDI® ARROW sprayers to be adapted to all kinds of terrain and crops.



NOTE: The cylinders move independently of each other.

Boom folding/unfolding




The folding/unfolding cylinder enables the boom to be placed in the unfolded (working) position or in the folded (transport) position.


Centrifugal blower units

By activating the folding/unfolding cylinder, the boom wings can be placed in their working or in their transport position.

Secure the boom while transporting the sprayer by inserting the snap locks once the boom wings are resting on the transport bar.



Elevation of the central support




The Central support lifting cylinder enables adjustment of the machine to suit the crop height.

There are two grease nipples to prevent seizing of the central support guide rail.

NOTE: This cylinder is optional.

Centrifugal blower units

Boom width adjustment



The position of the descending arm can be regulated with regards to width, in order to adapt the machine to match the row spacing. Once the required position has been chosen, locking bolts are employed to prevent any movement of the bar.

Centrifugal blower units




Gearbox oil change

The blower unit's gearbox is one of the mechanical elements that is put under the greatest strain.

During the spraying season, the gearbox oil level should be checked regularly and changed at the recommended intervals (see maintenance section).


1. Level gauge
2. Oil fill
3. Oil drainage



The oil drain is located on the underside of every gearbox.

The oil fill is on the top of the unit, behind the tank.

SAE-20/50 MULTIGRADE or **SAE-90** oil should be used in high-temperature zones.




Maintenance



Lubrication

P.T.O. shaft



The universal joints and bearings must be lubricated with grease. At points **(A)** this should be done after every **8 working hours**, and the tubes and axles **(B)** every **20 hours**.



NOTE. In all the HARDI® ARROW models, the P.T.O. shaft that connects the pump to the fan must also be greased.

Diaphragm pump

Grease the pump every **50 working hours** or once a month, through the grease nipple situated on the crankshaft axle. The **grease** goes along the grooves in the crankshaft to reach the crankcase where it is distributed around bearings, etc.



Hydraulically controlled section valves

Each hydraulically controlled section valve should be greased every **250 working hours** or once a year, or after cleaning the sprayer.



Maintenance

Drawbar

The **swivel drawbar** ① has a grease nipple **E** on its upper surface.

To avoid the wear and seizing up of the drawbar's rotating parts keep them greased at all times.

On the underside of the drawbar, the nut that holds the swivel head in place must also be greased.




The **turnable hitch drawbar** ② has two grease nipples, **E** and **F**.

These parts must be greased at least **once a year**.


Axles

The hub is the part of the axle that must be greased. Remove hub cap ③ and grease the inside of the rotating head. Grease at least **once a year**.



Filters and fittings

Whenever dismantling any **filter** or hose pipe take care not to pinch the o-rings fitted to them. When replacing the pipe fitting, smear the **o-ring** with **oil** or **grease** so that it falls easily into place in its groove.




Maintenance



Diaphragm pumps

The method of replacing the diaphragms is very simple:



Pump 363

- 1 Dismantle the crankcases (1).
- 2 Remove the valves (2) and o-rings (3).
- 3 Remove the diaphragms.
- 4 Remember to place the diaphragms (4) with piece number (5) upwards.
- 5 Reassemble the pump placing the valves in the correct position.



WARNING. Bear in mind that there are two different types of valves on the upper crankcases which must be replaced in the same position.




Nozzles - axial

For cleaning or replacement of the nozzles a spanner should be used to undo the nut (2). Remove the nozzle and clean it with air, water or a toothbrush.


Never use a piece of wire or a needle as this could cause irreparable damage to the nozzle.

If any of the nozzles leak on closing the sector the non-drip diaphragm should be replaced (1).



Nozzles - SPV, pneumatic

The ceramic nozzles come in various sizes. Depending on the required volume rate, they must be replaced or turned over. The normal sizes are 1099-08, 1099-10, 1099-12 and 1099-15. Check the Mistblowing Technique manual for other available sizes.




Maintenance


To replace the nozzles on machines with white **S** and SPV spout **R** follow the procedure indicated by the photographs.




Remove the nut to remove the nozzle.






The non-drip valve is situated at the connection between the spout and the sector hose **1**. Remove the nut **2** and inspect the diaphragm **B** and seat **A**.



In SPV-type units **4**, the non-drip valve is located on the inside of the nozzle and consists of a non-drip ball valve **C**. To check or replace the non-drip ball valve, dismantle as shown in figure **5** and take out the valve **C**.



On the high pressure white spouts **7** the non-drip valve is easily accessible on one of the sides. This non-drip valve incorporates a diaphragm **D** and is similar to the pneumatic type. To dismantle it, use a 3/4" (19 mm) wrench **E**.



Maintenance



Maintenance intervals

Every **10 working hours.**

- 1 Clean the suction filter.
- 2 Clean the pressure filters.
- 3 Check the nozzles.
- 4 Check for leaks in the fluid circuit.
- 5 Check for air intake into the suction.
- 6 Check the nuts and tighten if necessary.

Every **50 working hours.**

- 1 Carry out the aforementioned tasks.
- 2 Check the wheel nuts and tighten if necessary.
- 3 Check the P.T.O. shaft.
- 4 Check the tire pressure.
- 5 Grease the diaphragm pump. (If fitted)

Every **100 working hours.**

- 1 Carry out the aforementioned tasks.
- 2 Check and grease the drawbar.

Every **250 working hours.**

- 1 Carry out the aforementioned tasks.
- 2 Check the wheel hubs.
- 3 Check all the hoses.
- 4 Change the gearbox oil.
- 5 Grease hydraulic section valves.

Every **1000 working hours.**

- 1 Carry out the aforementioned tasks.
- 2 Service all the hubs.
- 3 Service the transmission.
- 4 Service the pump.
- 5 Service the gearbox.
- 6 Check the pressure gauge.
- 7 Service the clutch and fan.
- 8 Change the wheels.



CLEANING - Basic concepts



Cleaning procedures

The chemical product

Read the chemical product's label and those of the detergents and deactivating agents. Take note of any special instructions regarding protective clothing, deactivating agents, etc.

Legislation

Be familiar with local legislation regarding disposal of residues, mandatory decontamination methods, etc. If in doubt, consult the appropriate agricultural department in your area.

Cleaning and the soakaway

The residues can be disposed of on a special soakaway, not used for crop cultivation. Seepage or runoff of residue into watercourses, wells, springs, pools, etc must be avoided. The washings must not be disposed of in sewers.

The sprayer

Cleaning starts with calibration, as a well calibrated sprayer will ensure the minimum amount of remaining spray liquid.

The sprayer should be cleaned immediately after use, thereby leaving it ready for the next application while avoiding contact with mixed chemical products. This also prolongs the life of the components.

If it is necessary to leave spray liquid in the tank for a short period of time, unauthorized persons and animals must not have access to the sprayer.

If the product applied is corrosive, it is recommended to coat all metal parts of the machine before and after use with a suitable rust inhibitor.



REMEMBER.

1. Clean sprayers are safe sprayers.
2. A clean sprayer is always ready for action.
3. Clean sprayers are not damaged by pesticides and their solvents.



CLEANING - Basic concepts



Cleaning the sprayer

1. Dilute the remaining spray liquid in the tank with at least 10 parts of water and spray the liquid on trees that have already been treated. It is advisable to increase the forward speed (double it if possible) and reduce the pressure.
2. Select and use the appropriate protective clothing, such as rubber gloves, face mask, wellington boots, etc. Select an appropriate detergent for cleaning and a deactivating agent if necessary.
3. Wash the outside of the tractor and sprayer with detergent.
4. Clean the suction and pressure filters. Take care not to damage the mesh. Replace.
5. With the pump running, rinse the inside of the tank, remembering the tank roof too. Rinse and operate all the components that have been in contact with the chemical product. Before opening the nozzles make sure that the machine is on crops or the soakaway.
6. After all the liquid has been emptied out, stop the pump and fill at least 1/5 of the tank with clean water, and add detergent and/or deactivating agent, for example washing soda or triple ammonia.
7. Start the pump and operate all controls so that the liquid is distributed to all the components. Leave the nozzles until last.
8. Drain the tank and let the pump run dry. Stop the pump as soon as it becomes empty. Rinse the inside of the tank.
9. Fit the filters and nozzles and store the sprayer. The solvents used in the chemical products react very strongly. Store the sprayer with the tank lid removed.

Check periodically for corrosion and react accordingly.




Unforeseen interruptions

If an application must be interrupted unexpectedly, for example because of bad weather, and there is still liquid remaining in the tank it is advisable to flush the pump, operating unit and tubes.

Close the nozzles and stop the PTO. Close the suction filter valve and open the filter. Start the pump and immediately run clean water through the suction hose that leads to the pump and open the nozzles. Continue until clean water is coming through the nozzles. Stop the pump and reassemble the suction filter.

Off-season storage



Off-season storage

When the spraying season is over, you should devote some extra time to the sprayer. If chemical residues are left over in the sprayer for long periods, it can reduce the life of the individual components. To preserve the sprayer and protect the components, carry out the following off-season storage program:

1. Clean the sprayer completely - inside and outside - as described under "Cleaning the sprayer". Make sure that all valves, hoses and auxiliary equipment have been cleaned with detergent and flushed with clean water afterwards, so no chemical residues are left in the sprayer.
2. Renew any damaged seals and repair any leaks.
3. Empty the sprayer completely and let the pump work for a few minutes. Operate all valves and handles to drain as much water out of the spraying circuit as possible. Let the pump run until air is coming out of all nozzles.
4. Pour appr. 13 gal. (50 liters) anti-freeze mixture consisting of 1/3 automotive anti-freeze and 2/3 water into the tank.
5. Engage the pump and operate all valves and functions on the MANIFOLD system, etc. allowing the anti-freeze mixture to be distributed around the entire circuit. Activate the hydraulically controlled blower section valves so the anti-freeze is sprayed through the nozzles as well. The anti-freeze will also prevent O-rings, seals, diaphragms, etc. from drying out.
6. When the sprayer is dry, remove rust from any scratches or damages in the paint and touch up the paint.
7. Lubricate all lubricating points according to the lubricating scheme - regardless of intervals stated.
8. Remove the glycerine-filled pressure gauges and store them in a vertical position in frost free conditions.
9. Apply a thin layer of anti-corrosive oil (e.g. SHELL ENSIS FLUID, CASTROL RUSTILLO or similar) on all metal parts. Avoid oil on rubber parts, hoses and tires.
10. Fold the boom in transport position and relieve pressure from all hydraulic functions.
11. Relieve pressure from all hydraulic functions.
12. Wipe hydraulic snap-couplers clean and fit the dust caps.
13. Apply grease on all hydraulic ram piston rods which are not fully retracted in the barrel to protect against corrosion.



Off-season storage

14. Jack up the axle and place wooden blocks under the wheels to prevent moisture damage and deformation of the tires. Tire black can be applied to the tire side walls to preserve the rubber.
15. To protect against dust, the sprayer can be covered by a tarpaulin. Ensure ventilation to prevent condensation.



Preparation after off-season storage

After a storage period, the sprayer should be prepared for the next season the following way:

1. Remove the cover. (If fitted)
2. Remove the blocks from under the wheels and adjust the tire pressure.
3. Wipe off the grease from hydraulic ram piston rods.
4. Fit the pressure gauges again. Seal with Teflon tape.
5. Connect the sprayer to the tractor, including hydraulics.
6. Check all hydraulic functions.
7. Empty the tank of remaining anti-freeze.
8. Rinse the entire liquid circuit on the sprayer with clean water.
9. Fill with clean water and check all functions.

Troubleshooting




Operational problems

If all of the maintenance operations have been carried out, you should not have any problems with the sprayer. If there is a breakdown, it is nearly always due to the following factors:

- a. Small holes in the pump's suction tube reduce or completely nullify its capacity for suction.
- b. If the suction filter is clogged up, suction will be made more difficult or impossible and the pump will not work correctly.
- c. If the pressure filters are clogged up, pressure in the pressure gauge will rise but not so in the nozzles.
- d. Dirt in the valves may impede their complete closure. This will also worsen the pump's performance.
- e. If the pump has been badly assembled, especially the diaphragm lids (diaphragm pump) or the suction chamber (piston pump), air will be sucked in and the pump's capacity will be reduced or nullified.
- f. If some of the electrical components are dirty they will not make good contact.

Therefore always check that:

- 1 The suction, pressure and nozzle filters are clean.
- 2 The hoses are well-fitted and have no splits or cracks.
- 3 The joints and o-rings are in good condition.
- 4 The pressure gauge is in good condition. The correct dosage depends on its accuracy.
- 5 The operating unit is in good working order. Test it with clean water.
- 6 The electrical components are clean.



Trouble shooting

To help solve any problems consult this table before taking the machine to a repair workshop. If the problem is not in this table consult your nearest dealer.

Fault	Cause	Solution
No liquid comes out of the nozzles.	Air entering suction.	Check that the suction O-ring seals properly.
		Check the main suction hose and its connections.
		Make sure that the valve bodies and suction chamber are not loose.



Troubleshooting


Fault	Cause	Solution
No liquid comes out of the nozzles.	Air in the system.	Fill the suction hose with the water for initial filling.
	Suction or pressure filters obstructed.	Clean the filters.
		Check that the suction fitting is not obstructed or too near the bottom of the tank.
Lack of pressure.	Incorrect assembly.	The agitation restrictor is not fitted.
		The safety valve's spring does not close properly.
		The suction fitting inside the tank is obstructed.
	Pump valve blocked or worn.	Check for possible blockage or wear.
	Pressure gauge defective or dirty.	Check for obstruction of pressure gauge inlet.
Pressure drop.	Blocked filters.	Clean all filters. Fill with clean water and start up.
		If powdered product is being used, check that the agitation is on.
	Worn nozzles.	Check the flow through every one and replace those that exceed it by 10%.
	Air suction when emptying the tank.	Too much agitation. Disconnect the agitator to empty the tank.
Pressure raise.	The pressure filters are starting to block.	Clean all filters.
	Agitation restrictor.	Check for blockage by opening and closing agitation.
Foam production.	Air is entering the system.	Check for loose nuts/fittings/O-rings in the suction system.
	Excessive agitation	Close the agitation. Reduce the tractor's r.p.m.
		Use anti-foaming agent.

Troubleshooting

Fault	Cause	Solution
Liquid is leaking from the bottom of the pump.	Damaged diaphragms or plungers.	See maintenance section.
Excessive noise or vibrations in the blower unit.	The fan has lost it's counter-weight.	Take the fan to be re-balanced. Consult your dealer.
	The blower unit's nuts are loose.	Tighten the nuts.
	The clutch plates are broken or worn.	Change the fan clutch.
Vibrations or noises in the gearbox.	The gear is not properly engaged.	Put the gear lever in the correct position.
	Worn tooth-wheels.	Replace the tooth-wheels.
	Oil level below minimum.	Fill to the indicated level.





Technical data






Dimensions

ARROW 270 Axial Fan



ARROW 270 2-Row Grape Boom




Weights

Weights		
Model	Empty	Full
ARROW 270 Axial Fan	1477 lbs. (670 kg)	4719 lbs. (2140 kg)
ARROW 270 SPV 2-Row Grape Boom	1614 lbs. (730 kg)	4855 lbs. (2200 kg)


All the weights are approximate.

Technical data





Wheels

WHEELS (Tires & Rims)		
Model	Standard	Optional
Arrow 270	10.0/80 12" (8 ply)	275/50 R15"



Diaphragm pumps

Model 363/7



363/7	r/min											
	300		400		500		540		600		700	
PSI	gpm	Hp	gpm	Hp	gpm	Hp	gpm	Hp	gpm	Hp	gpm	Hp
0	20.6	1.2	27.5	1.6	34.6	2.1	37.0	2.1	41.2	2.5	48.3	3.0
29	20.1	1.3	26.9	1.7	33.8	2.3	35.9	2.4	40.1	2.7	46.7	3.1
58	19.5	1.7	25.9	2.0	33.0	2.5	35.1	2.8	38.8	3.2	44.9	3.8
88	19.3	1.9	25.6	2.4	31.9	3.1	34.3	3.4	38.0	3.9	44.1	4.7
147	18.7	2.4	25.1	3.2	30.9	4.2	33.5	4.6	37.2	5.1	43.3	6.2
220	18.5	3.2	24.3	4.3	30.4	5.2	32.7	5.9	36.2	6.7	42.5	7.9
294	18.0	3.9	23.8	5.2	29.8	6.4	32.2	7.2	35.6	7.9	41.7	9.4


Maximum pressure: 294 PSI (20 bar)

Weight: 116 lbs. (52.6 kg.)

Normal working revolutions: 540 r/min



General specifications



General specifications

Filters

Suction filter: 50 mesh: 0.012" (0.3 mm)

Pressure filter: 50 mesh: 0.012" (0.3 mm)

Working temperature and pressure

Temperature: 36°F to 104°F (2°C to 40°C)

Maximum pressure inside the manifold:

290 psi (20 bar)

Maximum pressure in the suction manifold:

102 psi (7 bar)

Materials

Tanks: UV resistant polyethylene

Hoses: PVC or rubber

Valves: PA with carbon fiber

Fittings: PA

Fan: Aluminum

Recycling

When the sprayer has reached the end of its useful working life, it must be thoroughly cleaned.

Many parts can be recycled.

The tank is 100% recyclable at a plastic recycling plant.

The hoses and synthetic fittings can be incinerated at an authorized disposal plant.

The aluminum parts of the fan can be taken to an aluminum recycling plant.

The metal parts can be taken to a scrapyard.

Always follow local legislation regarding disposal.


General specifications



Pictograms



Description



Agitation



Connecting the sprayer




Powder mixer



Fluid circuit



Clean water tank




Diaphragm pumps



Specifications



Operating units




Off-season storage



Filters



Operational problems



Axial blower




Maintenance



Centrifugal blower



Cleaning



Main tank



Warning



Nozzles



Lubrication



WARRANTY POLICY AND CONDITIONS

HARDI® INC. , 1500 West 76th Street, Davenport, Iowa, USA; 5646 W. Barstow, Fresno, California, USA; and 290 Sovereign Road, London, Ontario, Canada hereinafter called "HARDI®", offers the following limited warranty in accordance with the provisions below to each original retail purchaser of HARDI® new equipment of its own manufacturer, from an authorized HARDI® dealer, that such equipment is at the time of delivery to such purchaser, free from defects in material and workmanship and that such equipment will be warranted for a period of one year from the date of delivery to the end user providing the machine is used and serviced in accordance with the recommendations in the Operator's Manual and is operated under normal farm conditions.

1. This limited warranty is subject to the following exceptions:
 - a) Parts of the machine not manufactured by HARDI®, (i.e. engines, tires, tubes, electronic controls, and other components or trade accessories, etc.) are not covered by this warranty but are subject to the warranty of the original manufacturer. Any claim falling into this category will be taken up with the manufacturer concerned.
 - b) This warranty will be withdrawn if any equipment has been used for purposes other than for which it was intended or if it has been misused, neglected, or damaged by accident, let out on hire or furnished by a rental agency. Nor can claims be accepted if parts other than those manufactured by HARDI® have been incorporated in any of our equipment. Further, HARDI® shall not be responsible for damage in transit or handling by any common carrier and under no circumstances within or without the warranty period will HARDI® be liable for damages of loss of use, or damages resulting from delay or any consequential damage.
2. We cannot be held responsible for loss of livestock, loss of crops, loss because of delays in harvesting or any expense or loss incurred for labor, supplies, substitute machinery, rental for any other reason, or for injuries either to the owner or to a third party, nor can we be called upon to be responsible for labor charges, other than originally agreed, incurred in the removal or replacement of components.
3. The customer will be responsible for and bear the costs of:
 - a) Normal maintenance such as greasing, maintenance of oil levels, minor adjustments, etc.
 - b) Transportation of any HARDI® product to and from where the warranty work is performed.
 - c) Dealer travel time to and from the machine or to deliver and return the machine from the service workshop for repair.
 - d) Dealer traveling costs.
4. Parts defined as normal wearing items, (i.e. tires and V-belts) are not in any way covered under this warranty.
5. This warranty will not apply to any product which is altered or modified without the express written permission of HARDI® and/or repaired by anyone other than an Authorized Service Dealer.
6. Warranty is dependent upon the strict observance by the purchaser of the following provisions:
 - a) That this warranty may not be assigned or transferred to anyone.
 - b) That the Warranty Registration Certificate has been correctly completed by dealer and purchaser with their names and addresses, dated, signed and returned to the appropriate address as given on the Warranty Registration Certificate.
 - c) That all safety instructions in the operator's manual shall be followed and all safety guards regularly inspected and replaced where necessary.
7. No warranty is given on second-hand products and none is to be implied.

WARRANTY POLICY AND CONDITIONS

8. Subject to the following terms and conditions, HARDI® extends the warranty on polyethylene tanks on mist-blower sprayers with axial or centrifugal fans (excluding fittings, lids and gaskets) to TEN YEARS. To qualify for this extended warranty, the tank must be drained and flushed with fresh water after each day of use. HARDI®'s liability is limited to replacement of the tank, FOB our plants in Davenport, IA, USA; Fresno, CA, USA, and London, Ontario, Canada at no cost to the purchaser during the first ten years. This ten year extended warranty is subject, in each instance, to the tank being inspected and approved for replacement or repair by HARDI® personnel before HARDI® will accept any liability hereunder.
9. Subject to the following terms, conditions, contributions, HARDI® extends the warranty on HARDI® diaphragm pumps (excluding wearing parts such as diaphragms, valves, etc.) to FIVE YEARS. To qualify for this extended warranty, the pump must be drained and flushed with fresh water after each day of use. HARDI®'s liability is limited to replacement of defective parts, FOB our plants in Davenport, IA, USA; Fresno, CA, USA, and London, Ontario, Canada at no cost to the purchaser during the first twelve months after date of purchase, at 20% of the then current retail price during the second year ; at 40% during the third year ; at 60% during the fourth year ; and at 80% during the fifth year. This five year extended warranty is subject, in each instance, to the pump being inspected and approved for replacement or repair by HARDI® personnel before HARDI® will accept any liability hereunder.
10. HARDI® reserves the right to incorporate any change in design in its products without obligation to make such changes on units previously manufactured.
11. The judgement of HARDI® in all cases of claims under this warranty shall be final and conclusive and the purchaser agrees to accept its decisions on all questions as to defect and to the exchange of any part or parts.
12. No employee or representative is authorized to change this warranty in any way or grant any other warranty unless such change is made in writing and signed by an officer of HARDI® at its head office.
13. Any warranty work performed which will exceed \$400.00 MUST be approved IN ADVANCE by the Service Manager.
14. Any pump replacement must be approved in advance by the Service Manager.
15. Claims under this policy must be filled with HARDI® within thirty (30) days of work performed or warranty shall be void.
16. Parts requested must be returned prepaid within thirty (30) days for warranty settlement.
17. Warranty claims must be COMPLETELY filled out properly or will be returned.

DISCLAIMER OF FURTHER WARRANTY

THERE ARE NO WARRANTIES, EXPRESSED OR IMPLIED, EXCEPT AS SET FORTH ABOVE. THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION OF THE PRODUCT CONTAINED HEREIN. IN NO EVENT SHALL THE COMPANY BE LIABLE FOR INDIRECT, SPECIAL OR CONSEQUENTIAL DAMAGES (SUCH AS LOSS OF ANTICIPATED PROFITS) IN CONNECTION WITH THE RETAIL PURCHASER'S USE OF THE PRODUCT.

